

# Installation Guide

## 1 System Requirements

XP/Windows7/Windows10/Windows11

## 2 Hardware Required


- Host: A computer with a 1GHz or faster 32-bit (x86) or 64-bit (x64) processor.
- Memory: 1GB RAM (32-bit) operating system or 2GB RAM (64-bit) operating system.
- Hard disk space: more than 200MB.
- Display: 800×600 resolution.

## 3 Software Installation Procedure

1. Link website <https://www.tenmars.com/>
2. Click English in the upper right corner of the webpage.
3. Search TM-188D.
4. Click on the TM-188D photo.
5. Click **File Download**, then select **Software** Download.
6. Download and unzip the software.
7. Run autorun.exe, and click to install the following software.



8. Connect this product to a computer with included USB cable.



9. To execute desktop program: double click the program icon to start it.



10. See Software Installation Guide for details on software [User Manual](#).